


Installationsanleitung  
 Manuel d'installation  
 Installatiehandleiding  
 Manual de instalación  
 Manuale d'installazione  
 Εγχειρίδιο εγκατάστασης  
 Manual de instalação

Руководство по монтажу  
 Montaj kılavuzu  
 Installationsvejledning  
 Installationshandbok  
 Installeringshåndbok  
 Asennusopas  
 Instalační návod

Priručnik za postavljanje  
 Szerelési kézikönyv  
 Instrukcja montażu  
 Manual de instalare  
 Priročnik za montažo  
 Paigaldusjuhend  
 Ръководство за монтаж



Įrengimo vadovas  
 Uzstādīšanas rokasgrāmata  
 Návod na inštaláciu  
 Uputstvo za instaliranje  
 Manuali i instalimit

### ASYCPIR





		Ø9.5 → Ø6.4	Ø12.7 → Ø9.5	Ø15.9 → Ø12.7
RZAG35A	FDXM50F9		○	
	FFA50A9		○	
	FBA50A9		○	
	FCAG50A		○	
	FNA50A9		○	
	FTXM50N		○	
	FHA50A9		○	
RZAG60A	FBA71A9	○		
	FCAG71A	○		○
	FTXM71N			○
	FHA71A9	○		○

#### Ø9.5 → Ø6.4



#### Ø12.7 → Ø9.5



#### Ø15.9 → Ø12.7

