



- For all pinout connections please refer to the terminal unit manual.

- MAX 10 SLAVE UNIT ALLOWED.

(The slave local address is settable from 1 to 247, please refer to terminal unit manual).

- For the connections, is recommended the use of AWG 22/24 or 0.22-0.35mmq twisted and shielded cable, or equivalent suitable for RS485 modbus data communication.

- All the JUMPERS for SLAVE Mode must be set without the power supply.

The first system startup recognition procedure of the SLAVES UNITS takes about 10 minutes.

-Jumper provided inside the OPower electronic board.

EUROPO S.r.l. - Pordenone

DENOM.

Omnibus Round Local bus wiring diagram

Cod.: 580100000

Data: 24.02.21
Date:

R.M. Data-firma Modifiche

01 05/10/21 Morettin Update cable type. added missing informations